Do not disassemble the motor housing.This pump has NO repairable internal parts, and disassembling may cause leakage or dangerous electrical wiring conditions. If you have any questions regarding the product, please call customer service at 1-800-346-7611, 8 a.m. - 5 p.m. (EST), Monday – Friday.

Problem	Possible Cause	Corrective Action
Pump does not start or run	1. Blown fuse 2. Tripped breaker 3. Plug disconnected 4. Corroded plug 5. Thermal overload 6. Motor failed 7. Float switch failed 8. Float switch obstructed	1. Replace fuse 2. Reset breaker 3. Secure plug 4. Clean plug prongs 5. Unplug for 30 minutes, then plug in 6. Call 1-800-346-7611 7. Please call us at 1-800-346-7611 for a replacement float switch, or go to the store where you purchased this pump to purchase a new float switch 8. Make sure the float switch has room to move and is not getting caught on any obstructions. Make sure your pit is at least 14 in. wide
Pump operates but pumps little to no water	1. Screen blocked 2. Impeller loose on shaft 3. Impeller broken	1. Clean screen 2. Reassemble impeller 3. Call 1-800-346-7611